

Hearth Pad Dimensions

All dimensions are based on Black Metal Trim

Standard Pads

Size	Width	Depth	Front	Lop
32	32 1/2"	32 1/2"	16 3/16"	11 1/2"
36	36 1/2"	36 1/2"	15 11/16"	14 11/16"
40	40 1/2"	40 1/2"	19 11/16"	14 11/16"
4048	40 1/2"	48 1/2"	19 11/16"	14 11/16"
48	48 1/2"	48 1/2"	27 11/16"	14 11/16"
4854	48 1/2"	54 1/2"	27 11/16"	14 11/16"
54	54 1/2"	54 1/2"	30 3/16"	17 3/16"
60	60 1/2"	60 1/2"	36 3/16"	17 3/16"

Corner Pads

Size	Width	Depth	Side	Lop
32	32 1/2"	38 5/8"	22 1/8"	14 11/16"
36	36 1/2"	43"	24 3/8"	17 3/16"
40	40 1/2"	48 11/16"	28 3/8"	17 3/16"
48	48 1/2"	60"	36 3/8"	17 3/16"
54	54 1/2"	68 1/2"	42 3/8"	17 3/16"
60	60 1/2"	77"	48 3/8"	17 3/16"

Hearth Extensions

Size	Width	Depth	Front	Lop
4812	48 1/2"	12 1/2"	38 3/16"	7 1/4"
4818	48 1/2"	18 1/2"	38 3/16"	7 1/4"
4824	48 1/2"	24 1/2"	38 3/16"	7 1/4"


Wall Pads¹

Size	Width A	Height A	Width B	Height B
32	32 1/2"	32 1/2"	31 1/4"	32 1/2"
36	36 1/2"	36 1/2"	35 1/4"	36 1/2"
40	40 1/2"	40 1/2"	39 1/4"	40 1/2"
48	48 1/2"	48 1/2"	47 1/4"	48 1/2"
54	54 1/2"	54 1/2"	53 1/4"	54 1/2"
60	60 1/2"	60 1/2"	59 1/4"	60 1/2"


¹For corner installations you will have to order two Wall Pads (A and B), one of the pads will have 1 1/4" taken off the width to allow a flush fit during installation.

Tile Layout


Want to look at diagrams for all regular sizes? Visit graysenwoods.com/tools.




Standard



Corner



Hearth Extension



Wall

Need a hearth pad over 60"? Need a Hearth Extension other than 48" wide?

Not a problem! We can custom build the hearth or wall protector to suit your needs.